



# 检测报告

## Test Report

送检企业: 山西海森水泥制品有限公司

样品名称: 废气、废水、噪声

检验类别: 委托检验

  
厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250320B556

## 1. 检测信息

客户基本情况										
委托单位信息	单位名称	山西海森水泥制品有限公司								
	通讯地址	山西省运城市新绛县横桥镇原村村南								
	联系人	陈汝	联系电话	15635990190						
受检单位信息	单位名称	山西海森水泥制品有限公司								
	通讯地址	山西省运城市新绛县横桥镇原村村南								
	联系人	陈汝	联系电话	15635990190						
样品基本情况										
样品类别	样品名称	采样点位	采样频次		采样人员	采样时间	收样人员	收样时间	分析时间	样品状态描述
			天数	次/天						
废气	废气(无组织)	厂界上风向一个点	2	3	郭浩	2025.03.13	王明轩	2025.03.14	2025.03.13-2025.03.20	完好
		厂界下风向三个点	2	3	郭浩	2025.03.13	王明轩	2025.03.14	2025.03.13-2025.03.20	完好
噪声	昼夜噪声	厂界四周	2	3	郭浩	2025.03.13	王明轩	2025.03.14	2025.03.13-2025.03.20	完好
	白天噪声	工作场所	2	3	郭浩	2025.03.13	王明轩	2025.03.14	2025.03.13-2025.03.20	完好

报告编制: 张华伟

报告审核: 杨华群

报告签发: 杨华群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250320B556

## 2. 生产工单编号、检测类别、项目、方法、设备

表 2 检测分析方法及主要仪器设备一览表

样品类别	检测项目	检测方法	检测和分析设备	仪器编号	分析人员	最低检出限
废气 (无组织)	颗粒物	HJ/T398-2007	多功能声级计 AWA6228+ 声校准器 AWA6021A	04152	文军	-
噪声	昼夜噪声	工业企业厂界环境噪声排放标准 GB GB12348-2008	自动烟尘(气)测试仪 3012H 林格曼烟气浓度图 QT203M 手持式气象仪 NK5500 智能综合采样器 ADS.2062E.2.0 智能综合采样器 ADS.2062E.2.0 智能大气采样器 ADS.2062E 20 智能综合采样器 ADS.2062E(2.0) 低浓度称量恒温恒湿设备 JNVN.800S 十万分位天平 MS105DU 万分位天平 ME 204 电热恒温鼓风干燥箱 DHG.9203A 红外测油仪 OIL 480 紫外分光光度计 UV.1100 紫外可见分光光度计 UV.1800PC	04752	文军	-

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



### 3. 检测结果

表 3-1 无组织废气检测结果表

检测项目		检测结果(2025年03月13日)			检出限	单位	单项判定
		第一次	第二次	第三次			
粉尘	实测浓度	1.2	1.4	1.4	1.0	mg/m <sup>3</sup>	合格
	排放速率	3.92×10 <sup>3</sup>	4.64×10 <sup>3</sup>	4.25×10 <sup>3</sup>	...	kg/h	合格
总尘	实测浓度	17	18	17	3	mg/m <sup>3</sup>	合格
	排放速率	5.56×10 <sup>2</sup>	5.96×10 <sup>2</sup>	5.17×10 <sup>2</sup>	...	kg/h	合格
烟气黑度		<1	<1	<1	...	级	

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250320B556

检测项目		检测结果 (2025 年 03 月 14 日)			检出限	单位	单项判定
		第一次	第二次	第三次			
粉尘	实测浓度	1.1	1.4	1.8	1.0	mg/m <sup>3</sup>	合格
	排放速率	3.76×10 <sup>-3</sup>	4.38×10 <sup>3</sup>	5.64×10 <sup>3</sup>		kg/h	合格
总尘	实测浓度	17	16	16	3	mg/m <sup>3</sup>	合格
	排放速率	5.82×10 <sup>2</sup>	5.01×10 <sup>2</sup>	5.01×10 <sup>2</sup>	---	kg/h	合格
烟气黑度		<1	<1	<1	...	级	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250320B556

表 3-3 噪声检测结果表

检测点位	检测时间	检测结果 (2025 年 03 月 13 日)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:11:13~11:14	56.5	dB(A)	无	合格
	夜间:22:08~22:09	47.1	dB(A)	无	合格
N2 东厂界外 1 米	昼间:11:21~11:22	57.5	dB(A)	无	合格
	夜间:22:13~22:14	46.3	dB(A)	无	合格
N3 南厂界外 1 米	昼间:11:29~11:30	57.4	dB(A)	无	合格
	夜间:22:20~22:21	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:11:35~11:36	57.2	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250320B556

检测点位	检测时间	检测结果 (2025年03月14日)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:12:07~12:08	56.2	dB(A)	无	合格
	夜间:22:08~22:09	46.8	dB(A)	无	合格
N2 东厂界外 1 米	昼间:12:12~12:13	56.6	dB(A)	无	合格
	夜间:22:15~22:16	46.6	dB(A)	无	合格
N3 南厂界外 1 米	昼间:12:20~12:21	56.6	dB(A)	无	合格
	夜间:22:21~22:22	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:12:27~12:28	57.1	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250320B556

## 注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意, 不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议, 应于收到报告之日起十五日内向检测单位提出, 逾期不予受理。
6. 委托检测仅对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com