



# 检测报告

## Test Report

送检企业: 金涛阀门(温州)有限公司

样品名称: 平衡阀

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司  
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250311G125

样品名称	: 平衡阀	型号规格	: DN15-100
商标	: /	样品数量	: 1PCS
委托单位	: 金涛阀门(温州)有限公司		
委托单位地址	: 浙江省温州市温州经济技术开发区滨海五道 696 号光电及食药机械创业创新园 6 幢 401 室		
生产单位	: 金涛阀门(温州)有限公司		
生产单位地址	: 浙江省温州市温州经济技术开发区滨海五道 696 号光电及食药机械创业创新园 6 幢 401 室		
检验类别	: 委托检验	测试日期	: 2025 年 03 月 05 日-2025 年 03 月 11 日
签发日期	: 2025 年 03 月 11 日		
检验依据	: GB/T 12234-1989 《通用阀门 法兰和螺纹		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

报告签发:

杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司  
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250311G125

**检测结果:**

检验项目	单位	标准规定值	检 验 数 据	结 论
			2004 阀字 082	
壳体试验	WPa	试验压力: 15.3	15.3	合格
	S	特城时间 $\geq 60$	180	
	—	要求: 无可见渗漏、无结构损伤。	无可见渗漏、无结构损伤	
上密封试验	WPa	试验压力: 11.2	11.2	合格
	8	持续时间 $\geq 60$	120	
	—	要求: 无可见泄漏。	无可见洁涵。	
双向液体密封试验	Ta	试验压力: 11.2	11.2	合格
	S	持续时间 $\geq 60$	120	
	滴/min	要求: 泄漏量 $\leq 12$	0	
双向气体密封试验	Pa	试验压力: 0.4~0.7	0.6	合格
	S	持续时间 $\geq 60$	120	
	滴/min	要求: 泄漏量 $\leq 24$	0	
壳体最小壁厚		15.9	17.3	符合要求
阀杆最小直径		$\geq 28.6$	30.0	符合要求
外观质量	—	无有害缺陷。	无有害缺陷。	符合要求
装配质量		应连接牢固、启闭无卡阻现象。	连接牢固, 启闭无卡阻现象。	符合要求
阀体标志	—	应注有商标、公称通径。 公称压力、阀体材料代号。 熔炼炉号。	注有: 商标、公称通径。 公称压力、阀体材料代号。 熔炼炉号。	符合要求
备 注	阀体明示材质为 304 常温下, 压力级 600Lb 按温度-压力表对应的压力为 10.2Pa.			

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





## 注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com