



检测报告

Test Report

送检企业: 金涛阀门(温州)有限公司

样品名称: 过滤器

检验类别: 委托检验


厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250311G175

样品名称	: 过滤器	型号规格	: DN15-100
商标	: /	样品数量	: 1PCS
委托单位	: 金涛阀门(温州)有限公司		
委托单位地址	: 浙江省温州市温州经济技术开发区滨海五道 696 号光电及食药机械创业创新园 6 幢 401 室		
生产单位	: 金涛阀门(温州)有限公司		
生产单位地址	: 浙江省温州市温州经济技术开发区滨海五道 696 号光电及食药机械创业创新园 6 幢 401 室		
检验类别	: 委托检验	测试日期	: 2025 年 03 月 05 日-2025 年 03 月 11 日
签发日期	: 2025 年 03 月 11 日		
检验依据	: GB/T 13927-2008 工业阀门压力试验		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

报告签发:

杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250311G175

检测结果:

检测项目	技术要求	检测结果	单项判定
外观	表面应光滑, 无明显划痕、砂眼、气孔等缺陷, 油漆涂层均匀, 无脱落现象	表面光滑, 涂层均匀, 无缺陷	合格
尺寸精度	各部分尺寸应符合设计图纸要求, 偏差在允许范围内	经测量, 各尺寸偏差均在允许范围内	合格
材料成分	主要材料不锈钢 304, 其化学成分应符合相应标准规定, 如 $C \leq 0.08\%$, $Cr: 18.00 - 20.00\%$ 等	采用光谱分析仪检测, 材料成分符合标准	合格
压力试验 - 壳体试验	在规定试验压力, 1.5 倍公称压力, 假设公称压力为 1.6MPa, 则试验压力为 2.4MPa 下, 保持规定时间 5min, 壳体无渗漏、冒汗等现象	试验压力下保持 5min, 壳体无渗漏、冒汗	合格
压力试验 - 密封试验	在规定试验压力[如 1.1 倍公称压力, 即 1.76MPa]下, 保持规定时间[如 3min], 密封面无泄漏	试验压力下保持 3min, 密封面无泄漏	合格
过滤精度	应达到设计要求的过滤精度, 80 目, 即能有效过滤掉大于 0.15mm 的颗粒	通过标准试验粉尘进行过滤测试, 能有效过滤大于 0.15mm 颗粒	合格



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Addr: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com