



检测报告

Test Report

送检企业: 广宗县永泰档案制品有限公司

样品名称: 会计档案塑封袋

检验类别: 委托检验

厦门泓益检测有限公司

检验检测专用章

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250512A0176

样品名称	: 会计档案塑封袋	型号规格	: 25cm*36cm
商标	: /	样品数量	: 100PCS
委托单位	: 广宗县永泰档案制品有限公司		
委托单位地址	: 广宗县后马井工业区 8 号		
生产单位	: 广宗县永泰档案制品有限公司		
生产单位地址	: 广宗县后马井工业区 8 号		
检验类别	: 委托检验	测试日期	: 2025 年 05 月 06 日-2025 年 05 月 12 日
签发日期	: 2025 年 05 月 12 日		
检验依据	: GB/T 10004-2008		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制: 张华伟报告审核: 杨泽群报告签发: 杨泽群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250512A0176

检测结果:

序号	检验项目		单位	技术要求	检验结果	单项判定
1	拉断力	纵向	N	≥30	45.1	符合
		横向	N	≥30	48.0	符合
2	断裂标称应变	纵向	%	50 ~ 180	77	符合
		横向	%	15 ~ 90	63	符合
3	感官指标	外观		应平整, 无皱纹, 封边良好。不得有裂纹、孔隙和复合层分离	符合要求	符合
		袋装浸泡液		不得有异味、异臭、混浊和脱色现象	符合要求	符合
4	甲苯二胺		mg/L	≤0.004	未检出(检出限: 0.002mg/L)	符合
5	蒸发残渣	4%乙酸(60°C,2h)	mg/L	≤30	5.00	符合
		65%乙醇(常温, 2h)	mg/L	≤30	1.00	符合
		正己烷(常温, 2h)	mg/L	≤30	9.25	符合
6	高锰酸钾消耗量(水, 60°C,2h)		mg/L	≤10	0.729	符合
7	重金属(以 Pb 计, 4%乙酸, 60°C,2h)		mg/L	≤1	<1	符合

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com