



检测报告

Test Report

送检企业: 河北瑞龙生物科技有限公司

样品名称: 生活饮用水

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250415A1424

样品名称	: 生活饮用水	型号规格	: /
商标	: /	样品数量	: 5L+500mL*3 瓶
委托单位	: 河北瑞龙生物科技有限公司		
委托单位地址	: 河北省石家庄市开发区秦岭大街 439 号		
生产单位	: /		
生产单位地址	: /		
检验类别	: 委托检验	测试日期	: 2025 年 04 月 02 日-2025 年 04 月 15 日
签发日期	: 2025 年 04 月 15 日		
检验依据	: GB 5749-2022 《生活饮用水卫生标准》		
检验项目	: pH、臭和味、铅、肉眼可见物等 32 项		
样品特征和状态	: 液体、无色、透明		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制: 张华伟

报告审核: 杨泽群

报告签发: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250415A1424

序号	检测项目	单位	标准要求	检测结果	单项判定	检测方法
1	总大肠菌群	MPN/100mL	不应检出	未检出	符合	GB/T 5750.12-2023 5.1
2	大肠埃希氏菌	MPN/100mL	不应检出	未检出	符合	GB/T 5750.12-2023 7.1
3	菌落总数	CFU/mL	≤100	未检出	符合	GB/T 5750.12-2023 4.1
4	砷	mg/L	≤0.01	0.00087	符合	GB/T 5750.6-2023 9.4
5	镉	mg/L	≤0.005	<0.00006	符合	GB/T 5750.6-2023 12.4
6	铬(六价)	mg/L	≤0.05	<0.004	符合	GB/T 5750.6-2023 13.1
7	铅	mg/L	≤0.01	<0.00007	符合	GB/T 5750.6-2023 14.3
8	汞	mg/L	≤0.001	<0.0001	符合	GB/T 5750.6-2023 11.1
9	氰化物	mg/L	≤0.05	<0.002	符合	GB/T 5750.5-2023 7.2
10	氟化物	mg/L	≤1.0	0.21	符合	GB/T 5750.5-2023 6.2
11	硝酸盐 (以 N 计)	mg/L	≤10	0.80	符合	GB/T 5750.5-2023 8.3
12	亚硝酸盐	mg/L	≤0.7	0.2794	符合	GB/T 5750.10-2023 20.2
13	色度	度	≤15	<5	符合	GB/T 5750.4-2023 4.1
14	浑浊度	NTU	≤1	<0.5	符合	GB/T 5750.4-2023 5.1
15	臭和味	/	无异臭、异味	无任何臭和味	符合	GB/T 5750.4-2023 6.1
16	肉眼可见物	/	无	无	符合	GB/T 5750.4-2023 7.1

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





报告编号: HYI20250415A1424

17	pH	/	不小于 6.5 且 不大于 8.5	7.62	符合	GB/T 5750.4-2023 8.1
18	铝	mg/L	≤0.2	0.0666	符合	GB/T 5750.6-2023 4.5
19	铁	mg/L	≤0.3	0.0072	符合	GB/T 5750.6-2023 5.4
20	锰	mg/L	≤0.1	0.00013	符合	GB/T 5750.6-2023 6.6
21	铜	mg/L	≤1.0	<0.00009	符合	GB/T 5750.6-2023 7.6
22	锌	mg/L	≤1.0	<0.0009	符合	GB/T 5750.6-2023 8.4
23	氯化物	mg/L	≤250	11.9	符合	GB/T 5750.5-2023 5.2
24	硫酸盐	mg/L	≤250	27.6	符合	GB/T 5750.5-2023 4.2
25	溶解性总固体	mg/L	≤1000	268	符合	GB/T 5750.4-2023 11.1
26	总硬度 (以 CaCO ₃ 计)	mg/L	≤450	167	符合	GB/T 5750.4-2023 10.1
27	高锰酸盐指数 (以 O ₂ 计)	mg/L	≤3	1.59	符合	GB/T 5750.7-2023 4.1
28	氨 (以 N 计)	mg/L	≤0.5	<0.025	符合	GB/T 5750.5-2023 11.3
29	硒	mg/L	≤0.01	0.0006	符合	GB/T 5750.6-2023 10.4
30	钠	mg/L	≤200	8.0	符合	GB/T 5750.6-2023 25.4
31	挥发酚类 (以苯酚计)	mg/L	≤0.002	<0.002	符合	GB/T 5750.4-2023 12.1
32	阴离子合成洗涤剂	mg/L	≤0.3	<0.050	符合	GB/T 5750.4-2023 13.1
以下空白						

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20250415A1424

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无本实验室审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com