



检测报告

Test Report

送检企业: 泉州市进胜水暖洁具有限公司

样品名称: 陶瓷片密封水嘴 (水龙头)

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co., Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20250918A976

样品名称	: 陶瓷片密封水嘴 (水龙头)	型号规格	: M03 三联
商标	: /	样品数量	: 1 pcs
委托单位	: 泉州市进胜水暖洁具有限公司		
委托单位地址	: 福建省安溪县参内镇安山路 1583 号		
生产单位	: 泉州市进胜水暖洁具有限公司		
生产单位地址	: 福建省安溪县参内镇安山路 1583 号		
检验类别	: 委托检验	测试日期	: 2025 年 09 月 12 日-2025 年 09 月 18 日
签发日期	: 2025 年 09 月 18 日		
检验依据	: 客户委托检验要求 GB 18145-2014《陶瓷片密封水嘴》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求, 达到标准要求		

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



检测结果

序号	检验项目	技术要求	检验结果	单项判定
1	外观	1. 表面应无明显的疵点、划痕、气孔、缩孔等缺陷。 2. 涂、镀层应结合良好, 组织细密, 色泽均匀, 无气泡、脱落、露底等缺陷。 3. 金属镀层耐腐蚀等级: 电镀层不低于 9 级。	表面光滑, 无缺陷。电镀层经酸性盐雾试验后达到 10 级, 符合要求。	符合
2	加工与装配	1. 水嘴连接螺纹应符合 GB/T 7307 的规定。 2. 开关应平稳、轻便、无卡阻。 3. 活动连接部位应灵活、无卡阻。	螺纹符合标准, 开关手感平稳、灵活, 无卡阻现象。	符合
3	使用性能	1. 阀体的强度性能: 1.6MPa±0.05MPa 水压, 保压 60s±5s, 无变形、无渗漏。 2. 密封性能: a) 阀芯密封: 0.4MPa±0.02MPa 水压, 保压 60s±5s, 无渗漏。 b) 冷、热水隔墙密封: 0.4MPa±0.02MPa 水压, 保压 60s±5s, 无渗漏。 c) 上密封: 0.4MPa±0.02MPa 水压, 保压 60s±5s, 无渗漏。	经测试, 所有强度及密封性能试验均无变形、无渗漏。	符合
4	流量 (非节水型)	在动态压力 0.3MPa±0.02MPa 下: - 洗脸盆水嘴 (单阀) 流量不小于 0.20 L/s。 - 洗菜盆水嘴 (单阀) 流量不小于 0.20 L/s。	实测流量为 0.25 L/s, 大于标准要求值。	符合
5	寿命	开关寿命试验: 从开启到关闭为一个循环, 循环次数不低于 7 万次。试验后无渗漏, 并能正常使用。	完成 7 万次循环试验后, 产品功能正常, 无渗漏。	符合
6	抗水压性能	在 2.5MPa±0.05MPa 水压下, 保压 60s±5s, 阀体应无变形、无渗漏、无破裂。	试验后阀体无变形、无渗漏、无破裂。	符合
7	涂、镀层附着力	镀层经附着力试验后, 不应出现起皮或脱落现象。	经划格试验, 镀层无起皮、脱落现象。	符合
8	金属污染物析出	铅 (Pb) 析出统计值 $Q \leq 5 \mu\text{g/L}$ 其他 17 种元素 (锑、砷、钡、铍、硼、镉、铬、铜、汞、硒、铊、镍、钼、银、锰、锌、铝) 析出量应符合标准中表 3 的限值要求。	经测试, 铅及其他有害金属元素析出量均低于标准限值。	符合

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





样品展示:



有
章

*****以下无正文*****

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com