



检测报告

Test Report

送检企业: 武汉纳为科技有限责任公司

样品名称: 超声波流量计

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202503240A540

样品名称	:	超声波流量计	型号规格	:	NW-GDL200
商标	:	/	样品数量	:	1 pcs
委托单位	:	武汉纳为科技有限责任公司			
委托单位地址	:	湖北省武汉市东湖新技术开发区光谷三路 628 号山推楚天混凝土机械生产基地一期办公楼栋 2 层 209 室			
生产单位	:	武汉纳为科技有限责任公司			
生产单位地址	:	湖北省武汉市东湖新技术开发区光谷三路 628 号山推楚天混凝土机械生产基地一期办公楼栋 2 层 209 室			
检验类别	:	委托检验	测试日期	:	2025 年 03 月 13 日-2025 年 03 月 24 日
签发日期	:	2025 年 03 月 24 日			
检验依据	:	客户委托检验要求 JJ G 1030- 2007 超声流量计检定规程			
检验项目	:	见后续			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	63.8%
测试结果	:	本次委托检验, 所检项目全部符合标准要求, 达到标准要求			

报告编制: 张华伟

报告审核: 杨群

报告签发: 杨群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202503240A540

一、检定条件

介质种类: 水

介质温度: 29.0 °C

介质压力: 0.17MPa

二、检定结果

名义流量 (m³/h)	示值误差 (%)	检定前 流量计系数	检定后 流量计系数	重复性 (%)
160	0.29	1	0.919	0.04
64	0.30			0.08
20	-0.62			0.07

流量计的相对示值误差: -0.62%

重复性:0.08%

流量计系数调整量: $\frac{F-F_0}{F_0} = -8.10\%$

三、准确度等级: 1.0 级

四、安装条件

DN100mm,表前直管段长度大于 40D,V 型安装。

*****以下无正文*****

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com