



检测报告

Test Report

送检企业: 上海诚权厨房设备有限公司

样品名称: 两眼水池

检验类别: 委托检验


厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202575260A1305

样品名称	: 两眼水池	型号规格	: /
商标	: 诚权	样品数量	: 1PCS
委托单位	: 上海诚权厨房设备有限公司		
委托单位地址	: 上海市金山区朱泾镇鸿电路 233 号 5 幢、4 幢 1 层 A 区		
生产单位	: 上海诚权厨房设备有限公司		
生产单位地址	: 上海市金山区朱泾镇鸿电路 233 号 5 幢、4 幢 1 层 A 区		
检验类别	: 委托检验	测试日期	: 2025 年 10 月 12 日-2025 年 10 月 28 日
签发日期	: 2025 年 10 月 28 日		
检验依据	: GB/T 38160-2019 《不锈钢厨房设备》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

报告签发:



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202575260A1305

序号 SeriesNumber	检测项目 TestItems	技术要求 Requirement(s)	检测结果 TestResults	单项结论 ItemConclusion	备注 Remarks
1	外观	产品抛光后表面纹理应均匀一致, 外表面粗糙度 Ra 应不大于 3.2 μ m, 且不应有明显划痕、锤印及烧痕。	符合要求	符合	/
		产品焊接部位应牢固, 焊纹均匀一致, 不应有未焊透、裂纹等缺陷, 外露焊缝均应进行抛光或去色处理。	符合要求		
		产品各连接部位的紧固件应位置均匀, 连接牢固。	符合要求		
		操作及清洁时易接触部位, 不应有尖角和毛刺。	符合要求		
		不锈钢调理设备应易于清扫, 不应有滞留食物的凹陷处或死角。	符合要求		
2	结构	在不影响外观的条件下, 可以用挡、撑、加强筋、木板加固, 使用木板加固时木板需经过防潮、防腐处理。	符合要求	符合	/
		产品外形尺寸极限偏差为 ± 3 mm; 对角线长度之差应不大于 2mm。	+1mm		长
			-1mm		宽
			0mm		高
			2mm		对角线偏差
		洗涮台、操作台等装有防溅板的厨房设备, 防溅板对台面的垂直度应不大于 2mm。立柱与台面的垂直度应不大于 5mm。	最大 2mm		防溅板对台面
		贮藏柜类、推车类产品, 相邻两平面垂直度应不大于 5mm。	/		不适用
推车类车盘对立柱的垂直度应不大于 6mm/m, 存放架类横梁或层板对立柱的垂直度应不大于 6mm/m。					
洗涮台排水机构和水槽不应有渗水、漏水现象。当水槽容积 < 100 L 时, 排水机构应能在 2min 内将满水槽的水排净; 当水槽容积	符合要求	/			

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202575260A1305

序号 SeriesNumber	检测项目 TestItems	技术要求 Requirement(s)	检测结果 TestResults	单项结论 ItemConclusion	备注 Remarks
		≥100L 时, 排水机构无排水时间限制, 但排水最小口径不小于 50mm。			
		洗测台水槽底部、操作台台面搁板和底板、贮藏柜的搁板和底板均应能承受 100kg 载荷,其变形量应小于 3mm,如装有柜门和抽屉的产品,柜门、抽屉不得卡住。洗测台水槽承受 100kg 载荷后,不应有下沉、开裂、脱焊等异常现象。	1mm		
		推车类产品,车盘底部应能承受 50kg 载荷, 其变形量应小于 3mm。	/		
2	结构	产品在 490N 水平力的作用下, 框架的变形量应小于 15mm。去除作用力后,框架的变形量应小于 3mm。	2mm	符合	受力变形量
			0mm		残余变形量
		贮藏柜、推车等安装有柜门及抽屉的产品,柜门及抽屉应开闭灵活, 无异常杂音。	/		不适用
		安装有脚轮的推车行走时应平稳、灵活,无异常杂音。至少应有两个脚轮具有锁闭功能。			
通过保温水箱实现保温功能的不锈钢厨房设备,水箱应明示工作水位线。水箱不应出现加热封闭运行的情况。					
3	温升及保温性能	用电的保湿加热类设备,在 40℃~60℃工作温度范围内,其保温功能区的平均温升速度 v 应不小于 1℃/min。	/	/	不适用
		配备保温水箱的设备,在保温功能区温度达到 60℃后,停止加热,保温 30min 后,水箱内的水温应大于 45℃。			

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202575260A1305

序号 SeriesNumber	检测项目 TestItems		技术要求 Requirement(s)	检测结果 TestResults	单项结论 ItemConclusion	备注 Remarks	
4	表面 温升 , K	易接触部位(旋钮等)的表面	金属及其类似材料 ≤ 20	/	/	不适用	
			非金属材料 ≤ 30				
		壳体部位的表面					≤ 30
		开带 T-标志	$\leq (T-25)$				
		关、控温器及限温器的环境空间的环境空间或包围物	不带 T-标志 ≤ 30				
		导线的表面					≤ 50

以下空白 TEST REPORT END

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202575260A1305

样品照片



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Addr: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com