



检测报告

Test Report

送检企业: 宣城市宣一石材有限公司

样品名称: 雅典黑 (石材)

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI2025011200A1629

样品名称	:	雅典黑 (石材)	型号规格	:	100mm*100mm*20mm 200mm*200mm*30mm
商标	:	/	样品数量	:	6 块
委托单位	:	宣城市宣一石材有限公司			
委托单位地址	:	安徽省宣城市金坝办事处 318 国道傍长桥村桃园组 1 号			
生产单位	:	宣城市宣一石材有限公司			
生产单位地址	:	安徽省宣城市金坝办事处 318 国道傍长桥村桃园组 1 号			
检验类别	:	委托检验	测试日期	:	2025 年 11 月 07 日-2025 年 11 月 20 日
签发日期	:	2025 年 11 月 20 日			
检验依据	:	GB/T 18601-2024 天然花岗石建筑板材、GB/T9966.1-2001《天然饰面石材试验方法》、GB/T13891-2008《建筑饰面材料镜向光泽度测定方法》、GB6566-2010《建筑材料放射性核素限量》			
检验项目	:	见后续			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	62%
测试结果	:	本次委托检验, 所检项目全部符合标准要求			

报告编制: 张华伟

报告审核: 杨泽群



报告签发: 杨泽群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



序号	检测项目	检测指标	检测结果	单项判定
1	石材色斑	可见部位不允许有白斑、黑斑(石胆)	无色斑、无白胆	符合
2	石材色线	抛光部位不允许出现	未出现色线	符合
3	石材油斑、锈迹	石质表面要干净、不得带有油斑、锈迹	未出现油斑、锈迹	符合
4	石材色纹(水线)	可见部位不允许有色纹(水线)出现	未出现色纹(水线)	符合
5	石材裂纹	任意部位均不允许出现	未出现	符合
6	棱角缺陷	任意部位均不允许出现	未出现	符合
7	体积密度	$\geq 2.60\text{g/cm}^3$	2.66g/cm^3	符合
8	吸水率	$\leq 0.6\%$	0.3%	符合
9	干燥压缩强度	$\geq 100\text{ (MPa)}$	118 (MPa)	符合
10	干燥弯曲强度	$\geq 8.0\text{ (MPa)}$	12 (MPa)	符合
11	镜像光泽度(光泽)	≥ 100 光泽单位	120 光泽单位	符合
12	水饱和和压缩强度	$\geq 100\text{ (MPa)}$	115 (MPa)	符合
13	水饱和和弯曲强度	$\geq 8.0\text{ (MPa)}$	10 (MPa)	符合
14	抗冻系数	$\geq 95\%$	98%	符合
15	材料等级	符合 GB6566-2010《建筑材料放射性核素限量》	A 类	符合

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com