



检测报告

Test Report

送检企业: 白城市洮北区祥源塑料制品厂

样品名称: 聚乙烯(PE)软管

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



| | | | |
|---------|---|-------------|-------------------------------------|
| 样品名称 | : 聚乙烯 (PE) 软管 | 型号规格 / 质量等级 | : RG75X1.0-0.1MPa 合格品 |
| 商标 | : / | 样品数量 | : 50m |
| 委托单位 | : 白城市洮北区祥源塑料制品厂 | | |
| 委托单位地址 | : 白城市洮北区青山镇永红村 | | |
| 生产单位 | : 白城市洮北区祥源塑料制品厂 | | |
| 生产单位地址 | : 白城市洮北区青山镇永红村 | | |
| 检验类别 | : 委托检验 | 测试日期 | : 2026 年 01 月 29 日-2026 年 02 月 02 日 |
| 签发日期 | : 2026 年 02 月 02 日 | | |
| 检验依据 | : 《塑料节水灌溉器材 非复用型农用聚乙烯 (PE) 软管》(T/NZJS 3-2024); 《塑料节水灌溉器材: 第四部分 聚乙烯 (PE) 软管》(GB/T 19812.4-2018) | | |
| 检验项目 | : 见后续 | | |
| 样品特征和状态 | : 完好, 无损伤 | | |
| 环境温度 | : 24.6°C | 环境湿度 | : 62% |
| 测试结果 | : 本次委托检验, 所检项目全部符合 T/NZJS 3-2024 标准要求 | | |

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



| 序号 | 检验项目 | 检测依据 | 标准要求 | 实测数据 | 单项结论 |
|------|---------------------|-------------------|--|------------------------|------|
| 1 | 外观 | GB/T 19812.4-2018 | 软管颜色一般为黑色, 色泽应一致, 内外壁应光滑平整, 不应有气泡、破裂、划伤等缺陷。 | 符合 | 合格 |
| 2 | 公称壁厚 (0.4 MPa)mm | GB/T 9573-2013 | 1.0±0.1 | 最大值: 1.1 最小值: 1.0 | 合格 |
| 3 | 公称外径 mm | GB/T 9573-2013 | +1.5 75 -1.5 | 最大值: 76.5 最小值: 74.5 | 合格 |
| 4 | 耐静液压 | GB/T 6111-2018 | 试样在 (20±1)℃、1.5 倍公称压力 (0.375 MPa) 下保压 1h 而无渗漏、无破裂。 | 无渗漏、 无破裂 | 合格 |
| 5 | 瞬时爆破压力 MPa | GB/T 15560-1995 | ≥2.0 倍公称压力 (0.8 MPa)。 | 1.5 | 合格 |
| 6 | 拉伸屈服应力 MPa | GB/T 8804.3-2003 | ≥12 | 18 | 合格 |
| 7 | 断裂伸长率 % | GB/T 8804.3-2003 | ≥350 | 528 | 合格 |
| 8 | 耐环境应力开裂 | GB/T 15819-2006 | 试样不合格弯折数不超 10%。 | 0 | 合格 |
| 9 | 炭黑含量 % | GB/T 13021-1991 | 1.0~5.0 | 1.4 | 合格 |
| 以下空白 | | | | | |



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Addr: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com