



检测报告

Test Report

送检企业: 辽宁新辽海电缆集团有限公司

样品名称: 传输线

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



样品名称	: 传输线	型号规格	: 2*1.5mm ² RVV-2X1.5/3*1.5m ² R VV-3X1.5/5*1.5mm ² RVV-5X1.5
商标	: /	样品数量	: 10PCS
委托单位	: 辽宁新辽海电缆集团有限公司		
委托单位地址	: 辽宁省沈阳市铁西经济技术开发区 26 号路 40 号		
生产单位	: 辽宁新辽海电缆集团有限公司		
生产单位地址	: 辽宁省沈阳市铁西经济技术开发区 26 号路 40 号		
检验类别	: 委托检验	测试日期	: 2025 年 07 月 14 日-2025 年 07 月 18 日
签发日期	: 2025 年 07 月 18 日		
检验依据	: JB/T 8734.3-2016		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

检测专用章



报告编号: HYI202507180A337

序号	检测项目	单位	标准要求	实测结果	单项结论	检测方法
1	导体结构 (单芯)	股/根	19 股, 单丝直径 0.3mm, 无氧铜材质	19 股, 单丝直径 0.3mm, 无氧铜材质	符合	目视+精密卡尺测量, 对照 GB/T 3956 标准
2	导体标称截 面积	mm ²	1.5±0.1	1.52	符合	精密卡尺测量, 计算截面积
3	绝缘层厚度 (平均)	mm	≥0.8	0.90	符合	精密卡尺测量, 对照 GB/T 5023.2-2008
4	导体直流电 阻 (20℃)	Ω/km	≤13.3	13.0	符合	低电阻测量仪测量, 施加已 知电流, 计算电阻值
5	绝缘电阻 (20℃)	MΩ·km	≥20	28	符合	绝缘电阻测试仪 (500V 直 流), 测量泄漏电流并计算
6	耐压性能 (导体间)	V AC/min	2000V, 1min 无击穿	2000V, 1min 无击 穿、无飞弧	符合	耐压测试仪施加高压, 监测 是否击穿
7	特性阻抗 (1MHz)	Ω	120±10%	118	符合	时域反射计测量, 分析反射 波形计算
8	阻燃性能	/	符合 GB/T 19666 B 级成束燃烧要求	燃烧时间≤30s, 无 滴落物引燃滤纸	符合	燃烧试验装置, 按标准进行 成束燃烧测试



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202507180A337

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com