



检 测 报 告

Test Report

送检企业: 哈密宾馆有限责任公司

样品名称: 生产用水

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202603140A189

样品名称	:	生产用水	型号规格	:	/
商标	:	/	样品数量	:	4L
委托单位	:	哈密宾馆有限责任公司			
委托单位地址	:	新疆哈密市伊州区宾园路 14 号			
生产单位	:	哈密宾馆有限责任公司			
取样地址	:	新疆哈密市伊州区宾园路 14 号			
检验类别	:	委托检验	测试日期	:	2026 年 03 月 04 日-2026 年 03 月 14 日
签发日期	:	2026 年 03 月 14 日			
检验依据	:	GB 5749-2022 《生活饮用水卫生标准》			
检验项目	:	见后续			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	62%
测试结果	:	不做判定			

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.
地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号
ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,
邮箱: hongyotest@123.com



报告编号: HYI202603140A189

序号	检测项目	单位	检测指标	检测结果	判定
1	总大肠菌群	(MPN/100mL)	不得检出	未检出	合格
2	大肠埃希氏菌	(MPN/100mL)	不得检出	未检出	合格
3	菌落总数	(CFU/mL)	≤ 100	未检出	合格
4	砷	(mg/L)	≤ 0.01	< 0.001	合格
5	镉	(mg/L)	≤ 0.0005	< 0.0005	合格
6	铬(六价)	(mg/L)	≤ 0.05	< 0.004	合格
7	铅	(mg/L)	≤ 0.01	< 0.0025	合格
8	汞	(mg/L)	≤ 0.001	< 0.0001	合格
9	氰化物	(mg/L)	≤ 0.05	< 0.004	合格
10	氟化物	(mg/L)	≤ 1	< 0.03	合格
11	硝酸盐	(mg/L)	≤ 10	5	合格
12	三氯甲烷	(mg/L)	≤ 0.06	0.0015	合格
13	一氯二溴甲烷	(mg/L)	≤ 0.1	< 0.02	合格
14	二氯一溴甲烷	(mg/L)	≤ 0.06	0.0013	合格
15	三溴甲烷	(mg/L)	≤ 0.1	< 0.02	合格
16	三卤甲烷	(mg/L)	≤ 1	< 0.03	合格
17	二氯乙酸	(mg/L)	≤ 0.05	0.0011	合格
18	三氯乙酸	(mg/L)	≤ 0.1	< 0.02	合格
19	溴酸盐	(mg/L)	≤ 0.01	< 0.0025	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202603140A189

20	亚氯酸盐	(mg/L)	≤ 0.7	0.4	合格
21	氯酸盐	(mg/L)	≤ 0.7	0.5	合格
22	色度	(铂钴色度单位)	≤ 15	<5	合格
23	浑浊度	(NTU)	≤ 1	<0.5	合格
24	臭和味	/	无异臭异味	无异臭异味	合格
25	肉眼可见物	/	无	无	合格
26	pH	(无量纲)	6.5~8.5	8.18	合格
27	铝	(mg/L)	≤ 0.2	0.085	合格
28	铁	(mg/L)	≤ 0.3	<0.05	合格
29	锰	(mg/L)	≤ 0.1	<0.02	合格
30	铜	(mg/L)	≤ 1	<0.03	合格
31	锌	(mg/L)	≤ 1	<0.03	合格
32	氯化物	(mg/L)	≤ 250	150	合格
33	硫酸盐	(mg/L)	≤ 250	27.92	合格
34	溶解性总固体	(mg/L)	≤ 1000	208	合格
35	总硬度	(mg/L)	≤ 450	137.6	合格
36	高锰酸盐指数	(mg/L)	≤ 3	1.75	合格
37	氨	(mg/L)	≤ 0.5	0.35	合格
38	总 α 放射性	(Bq/L)	≤ 0.5	<0.028	合格
39	总 B 放射性	(Bq/L)	≤ 1	<0.07	合格
40	游离余氯	(mg/L)	0.3~4	0.80	合格
41	总氯	(mg/L)	≤ 3	1	合格
42	臭氧	(mg/L)	≤ 0.3	0.15	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202603140A189

43	二氧化氯	(mg/L)	≤ 0.8	0.4	合格
----	------	--------	------------	-----	----

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com

有
限
公
司
章



报告编号: HYI202603140A189

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com