



检测报告

Test Report

送检企业: 华谊环保设备科技(江苏)有限公司

样品名称: 不锈钢环保果皮箱

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260425A230

样品名称	:	不锈钢环保果皮箱	型号规格	:	/
商标	:	/	样品数量	:	2
委托单位	:	华谊环保设备科技（江苏）有限公司			
委托单位地址	:	宿迁市宿豫高新区香山路 101 号			
生产单位	:	华谊环保设备科技（江苏）有限公司			
取样地址	:	宿迁市宿豫高新区香山路 101 号			
检验类别	:	委托检验	测试日期	:	2026 年 04 月 20 日-2026 年 04 月 25 日
签发日期	:	2026 年 04 月 25 日			
检验依据	:	《不锈钢冷轧钢板和钢带》(GB/T3280-2015)《金属材料维氏硬度试验第 1 部分:试验方法》(GB/T4340.1-2009《色漆和清漆漆膜的划格试验》(GB/T 9286-2021)《金属和合金的腐蚀不锈钢晶间腐蚀试验方法》(GB/T4334-2020)《焊接质量保证钢熔化焊接头的要求和缺陷分级》(GB/T19418-2003)			
检验项目	:	见后续页			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	62%
测试结果	:	本次委托检验, 所检项目全部符合要求			

报告编制: 张华伟

报告审核: 杨华群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.
地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号
ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,
邮箱: hongyotest@123.com



报告编号: HYI20260425A230

序号	项目	技术要求	检测结果	判定结果
1	外形规格尺寸	$\geq 900 \times 330 \times 1020 \text{mm}$	实测 $912 \times 335 \times 1025 \text{mm}$, 满足 $\geq 900 \times 330 \times 1020 \text{mm}$ 要求	合格
2	箱盖材质与厚度	201 不锈钢, 厚度 0.8 (± 0.05) mm	材质: 201 不锈钢; 厚度: 0.82mm, 在 0.75~0.85mm 范围内	合格
3	箱盖工艺	激光切割下料、数控折弯、整体焊接牢固, 打磨防锈处理	工艺符合要求, 切割边缘平整, 折弯角度标准, 焊缝打磨光滑, 无毛刺、无锈蚀	合格
4	箱体材质与厚度	201 不锈钢, 厚度 0.8 (± 0.05) mm	材质: 201 不锈钢; 厚度: 0.81mm, 在 0.75~0.85mm 范围内	合格
5	废弃物投口	工艺规整, 边缘光滑无毛刺	投口边缘打磨光滑, 无锐边、毛刺, 尺寸规整	合格
6	底座材质与安装	201 不锈钢, 厚度 0.8 (± 0.05) mm; 配固定梁, 不少于 4 只膨胀螺栓固定	材质: 201 不锈钢; 厚度: 0.80mm; 固定梁齐全, 预留 4 个螺栓孔, 可满足固定要求	合格
7	锁具性能	三角锁, 佩戴拉手, 锁闭牢靠, 钥匙统一配置	三角锁开启 / 关闭顺畅, 锁闭牢靠, 拉手安装牢固, 钥匙可统一开启	合格
8	内胆材质与厚度	201 不锈钢, 厚度 $\geq 0.38 \text{mm}$	材质: 201 不锈钢; 厚度: 0.40mm, $\geq 0.38 \text{mm}$	合格
9	内胆规格	单个内胆尺寸 $\geq 250 \times 310 \times 430 \text{mm}$ ($\pm 10 \text{mm}$)	实测内胆尺寸: $255 \times 315 \times 435 \text{mm}$, 满足 $\geq 250 \times 310 \times 430 \text{mm}$ 要求	合格
10	内胆性能	耐高温、双面光滑, 防腐阻燃	内胆表面双面光滑, 无毛刺、无锈蚀; 经阻燃性测试, 无明显火蔓延; 耐腐蚀测试合格	合格
11	内胆底部提手	设有 2 个提手, 方便倾倒垃圾	内胆底部设有 2 个不锈钢提手, 焊接牢固, 可稳定承托内	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260425A230

序号	项目	技术要求	检测结果	判定结果
			胆	
12	整体外观	光滑平整, 色泽明亮, 无明显接疤; 焊接均匀, 无虚焊漏焊	整体外观光洁平整, 色泽均匀, 无划痕、无接疤; 焊缝饱满均匀, 无虚焊、漏焊、气孔	合格
13	结构工艺	整体设计合理、美观大方	结构稳固, 双桶设计合理, 外形美观, 符合公共环境设施要求	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com

有
章



报告编号: HYI20260425A230

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com

厦门泓益检测有限公司