



检测报告

Test Report

送检企业: 浙江东雅教学设备有限公司

样品名称: 废气、噪声

检验类别: 委托检验


厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260512A163

1. 检测信息

客户基本情况											
委托单位信息	单位名称	浙江东雅教学设备有限公司									
	通讯地址	浙江省丽水市缙云县新碧街道碧兴路 141 号									
	联系人	陈敏	联系电话	19945775640							
受检单位信息	单位名称	浙江东雅教学设备有限公司									
	生产地址	浙江省丽水市缙云县新碧街道碧兴路 141 号									
	联系人	陈敏	联系电话	19945775640							
样品基本情况											
样品类别	样品名称	采样点位	采样频次		采样人员	采样时间	收样人员	收样时间	分析时间	样品状态描述	
			天数	次/天							
废气	废气(有组织)	P1 排气筒	2	3	郭浩	2026.05.05	王明轩	2026.05.06	2026.05.05-2026.05.12	完好	
	废气(无组织)	厂界上风向一个点	2	3	郭浩	2026.05.05	王明轩	2026.05.06	2026.05.05-2026.05.12	完好	
		厂界下风向三个点	2	3	郭浩	2026.05.05	王明轩	2026.05.06	2026.05.05-2026.05.12	完好	
噪声	昼夜噪声	厂界四周	2	3	郭浩	2026.05.05	王明轩	2026.05.06	2026.05.05-2026.05.12	完好	
	白天噪声	工作场所	2	3	郭浩	2026.05.05	王明轩	2026.05.06	2026.05.05-2026.05.12	完好	

报告编制:

张华伟

报告审核:

杨华群

报告签发:

杨华群

签发日期: 2026.5.15

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260512A163

2. 生产工单编号、检测类别、项目、方法、设备表 2 检测分析及主要仪器设备一览表

样品类别	检测项目	检测方法	检测和分析设备	仪器编号	分析人员	最低检出限
废气 (无组织)	颗粒物、粉尘	《大气污染物综合排放标准》 GB 16297-1996	X836 多功能声级计 AWA6228+ 声校准器 AWA6021A 自动烟 尘(气)测试仪 3012H 林格曼 烟气浓度图 QT203M 手持式 气象仪 NK5500	04152	文军	-
废气 (有组织)	颗粒物、粉尘	《大气污染物综合排放标准》 GB 16297-1996	智能综合采样器 ADS. 2062E. 2.0 智能综合采样器 ADS. 2062E. 2.0 智能大气采样器 ADS. 2062E 20 智能综合采样器 ADS. 2062E (2.0)	04152	文军	-
噪声	昼夜噪声	工业企业厂界环境噪声排放标 准 GB GB12348-2008	低浓度称量恒温恒湿设备 JNVN. 800S 十分位天平 MS105DU 万分位天平 ME 204 电热恒温鼓风干燥箱 DHG. 9203A 红外测油仪 OIL 480 紫外分光光度计 UV. 1100 紫外可见分光光度计 UV. 1800PC	04752	文军	-

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260512A163

3. 检测结果

表 3-1 有组织废气检测结果表

检测项目		检测结果 (2026. 05. 05)			检出限	单位	单项判定
		P1 排气筒出口					
		第一次	第二次	第三次			
颗粒物、粉尘	实测浓度	1.2	1.4	1.4	1.0	mg/m ³	合格
	排放速率	3.92×10 ³	4.64×10 ³	4.25×10 ³	...	kg/h	合格
颗粒物、粉尘	实测浓度	17	18	17	3	mg/m ³	合格
	排放速率	5.56×10 ²	5.96×10 ²	5.17×10 ²	...	kg/h	合格
烟气黑度		<1	<1	<1	...	级	

无组织废气检测结果表

检测项目	采样时间		检测结果				检出限	单位	单项判定
			G1 上风向	G2 下风向	G3 下风向	G4 下风向			
颗粒物、粉尘	2026. 05. 05	第一次	0.121	0.151	0.138	0.156	0.002	mg/m ³	合格
		第二次	0.104	0.156	0.171	0.156			合格
		第三次	0.122	0.131	0.139	0.157			合格
	2026. 05. 05	第一次	0.351	0.153	0.136	0.170			合格
		第二次	0.103	0.188	0.153	0.153			合格
		第三次	0.359	0.132	0.153	0.136			合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260512A163

表 3-4 噪声检测结果表

检测点位	检测时间	检测结果(2026. 05. 05)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:11:13~11:14	56.1	dB(A)	无	合格
	夜间:22:08~22:09	47.2	dB(A)	无	合格
N2 东厂界外 1 米	昼间:11:21~11:22	57.3	dB(A)	无	合格
	夜间:22:13~22:14	46.4	dB(A)	无	合格
N3 南厂界外 1 米	昼间:11:29~11:30	57.4	dB(A)	无	合格
	夜间:22:20~22:21	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:11:35~11:36	57.6	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

检测点位	检测时间	检测结果(2026. 05. 06)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:12:07~12:08	56.3	dB(A)	无	合格
	夜间:22:08~22:09	46.8	dB(A)	无	合格
N2 东厂界外 1 米	昼间:12:12~12:13	56.6	dB(A)	无	合格
	夜间:22:15~22:16	46.2	dB(A)	无	合格
N3 南厂界外 1 米	昼间:12:20~12:21	56.3	dB(A)	无	合格
	夜间:22:21~22:22	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:12:27~12:28	57.2	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260512A163

附: 噪声检测布点



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260512A163

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意, 不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议, 应于收到报告之日起十五日内向检测单位提出, 逾期不予受理。
6. 委托检测仅对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com