



# 检测报告

## Test Report

送检企业: 湖北永祥粮食机械股份有限公司

样品名称: 全自动智能变频砬谷机

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



样品名称	: 全自动智能变频磨谷机	型号规格	: MLGQ51E
商标	: 永祥	样品数量	: 1PCS
委托单位	: 湖北永祥粮食机械股份有限公司		
委托单位地址	: 湖北省安陆市府河大道 2 号		
生产单位	: 湖北永祥粮食机械股份有限公司		
生产单位地址	: 湖北省安陆市府河大道 2 号		
检验类别	: 委托检验	测试日期	: 2026 年 03 月 27 日-2026 年 03 月 30 日
签发日期	: 2026 年 03 月 30 日		
检验依据	: GB/T29898-2013 《粮油机械胶辊磨谷机》； JB/T10267-2013 《胶辊磨谷机》； Q/HYX03-2026 《全自动智能变频磨谷机》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验，所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

报告签发:





报告编号: HYI202603300A1337

序号	检测项目	技术标准要求	实测数据	判定
1	加工产量	中长粒稻(粳米): 7~9t/h 短粒稻(粳米): 8~11t/h	实测 8.5t/h	合格
2	电机配置	防爆变频电机≥2台, 变频 可调速	配置 2 台防爆变频三相电机, 变频 调速正常	合格
3	机械性能	运转应正常平稳, 无异常振 动、声响。正常运行时, 空 载噪声不大于 85dB(A)	运行平稳, 空载噪声 66dB(A) 满载工作噪声 88dB(A)	合格
		正常运行时, 轴承温升≤ 35℃, 最高温度≤75℃。	轴承温升 13℃, 轴承最高温度 37℃	合格
4	自动化控制	设备动作顺序, 可实现来料 自动紧辊, 无料自动松辊; 辊间压力由气压表线性控 制, 产量数字化调节显示; 采用同步带轮系转向	符合	合格
5	胶辊	摆动辊组件辅助支撑装置 ≥3 组	装配 3 组辅助支撑, 辊体运行无晃 动	合格
8	胶辊驱动	双气缸控制开合	双气缸同步伸缩, 胶辊启闭平稳无 冲击卡顿	合格
9	防爆性能	电机整机防爆参数符合防 爆规范	防爆标识齐全, 防爆防护达标	合格



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202603300A1337

## 注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com