



# 检测报告

## Test Report

送检企业: 杭州良悦实业有限公司

样品名称: 医疗舱空调

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



样品名称	: 医疗舱空调	型号规格	: /
商标	: /	样品数量	: 1pcs
委托单位	: 杭州良悦实业有限公司		
委托单位地址	: 浙江省杭州市拱墅区海辰水岸晶座3幢612室		
检验类别	: 委托检验	测试日期	: 2026年05月22日-2026年06月18日
签发日期	: 2026年06月18日		
检验依据	: QC/T 656-2018《客车空调系统技术条件》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制: 张华伟

报告审核: 杨群





序号	检测项目	技术标准要求	实测检测结果	判定
1	空调独立运行性能	驾驶室空调、医疗舱空调为各自独立冷暖一体系统,可单独开启、单独关闭,运行过程互不干扰、互不影响,功能完全独立	分别单独开启、同时开启两套空调系统,驾驶室与医疗舱空调运行状态独立可控,工作逻辑正常,无功能冲突、无相互干扰现象	合格
2	外接电源驻车运行性能	空调系统支持外接电源供电模式,可在车辆驻车静止状态下长期稳定连续运行,满足医疗驻车作业温控需求	外接电源接入后,空调系统启动正常、电压稳定、运行平稳,长时间驻车运行无停机、无报错、无过载现象,持续工作性能稳定	合格
3	医疗舱出风性能	医疗舱制冷出风口分布合理、覆盖均匀,出风量大、送风通畅,无风量阻滞、无局部无风、无异常出风噪音	医疗舱各出风口出风均匀、风量充足,送风顺畅无滞留、无阻滞,舱内全域送风覆盖良好,出风性能优良	合格
4	空调 3 分钟快速降温性能	标准高温测试工况下,空调开启制冷 3 分钟内,医疗舱内降温幅度不低于 10℃	初始舱内高温工况下启动制冷,3 分钟实测降温 11.2℃,降温幅度满足 $\geq 10^\circ\text{C}$ 技术要求	合格
5	空调 10 分钟持续降温性能	标准高温测试工况下,空调开启制冷 10 分钟内,医疗舱内降温幅度不低于 15℃	持续制冷 10 分钟,实测舱内总降温 16.8℃,降温幅度满足 $\geq 15^\circ\text{C}$ 技术要求	合格



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260618A1419

## 注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com