



检测报告

Test Report

送检企业: 坚真科技南通有限公司

样品名称: 噪 音

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260629A1115

1. 检测信息

客户基本情况										
委托单位信息	单位名称	坚真科技南通有限公司								
	通讯地址	海安市曲塘镇东联路 200 号								
	联系人	/	联系电话	/						
受检单位信息	单位名称	坚真科技南通有限公司								
	通讯地址	海安市曲塘镇东联路 200 号								
	联系人	/	联系电话	/						
样品基本情况										
样品类别	样品名称	采样点位	采样频次		采样人员	采样时间	收样人员	收样时间	分析时间	样品状态描述
			天数	次/天						
噪声	昼夜噪声	厂界四周	2	4	郭浩	2026.06.20	王明轩	2026.06.20	2026.06.20-2026.06.29	完好
	白天噪声	厂界四周	2	4	郭浩	2026.06.21	王明轩	2026.06.21	2026.06.21-2026.06.29	完好

报告编制: 张华伟

报告审核: 杨华群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260629A1115

2. 生产工单编号、检测类别、项目、方法、设备

表 2 检测分析方法及主要仪器设备一览表

样品类别	检测项目	检测方法	检测和分析设备	仪器编号	分析人员	最低检出限
噪声	生产噪声	GB 12348-2008 《工业企业厂界环境噪声排放标准》	多功能声级计 AWA6228+ 声校准器 AWA6021A	04152	文军	-
				04752	文军	-

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260629A1115

3. 检测结果

表 3-1 噪声检测结果表

检测点位	检测时间	检测结果 (2026年06月20日)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:11:13~11:14	56.5	dB(A)	无	合格
	夜间:22:08~22:09	47.1	dB(A)	无	合格
N2 东厂界外 1 米	昼间:11:21~11:22	57.5	dB(A)	无	合格
	夜间:22:13~22:14	46.3	dB(A)	无	合格
N3 南厂界外 1 米	昼间:11:29~11:30	57.4	dB(A)	无	合格
	夜间:22:20~22:21	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:11:35~11:36	57.2	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260629A1115

检测点位	检测时间	检测结果 (2026年06月21日)	单位	主要声源	单项判定
		Leq			
N1 北厂界外 1 米	昼间:12:07~12:08	56.2	dB(A)	无	合格
	夜间:22:08~22:09	46.8	dB(A)	无	合格
N2 东厂界外 1 米	昼间:12:12~12:13	56.6	dB(A)	无	合格
	夜间:22:15~22:16	46.6	dB(A)	无	合格
N3 南厂界外 1 米	昼间:12:20~12:21	56.6	dB(A)	无	合格
	夜间:22:21~22:22	46.4	dB(A)	无	合格
N4 西厂界外 1 米	昼间:12:27~12:28	57.1	dB(A)	无	合格
	夜间:22:26~22:27	46.5	dB(A)	无	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260629A1115

注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com