



# 检测报告

## Test Report

送检企业: 杭州良悦实业有限公司

样品名称: 设备隔振器

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



样品名称	: 设备隔振器	型号规格	: /
商标	: /	样品数量	: 3PCS
委托单位	: 杭州良悦实业有限公司		
委托单位地址	: 浙江省杭州市拱墅区海辰水岸晶座 3 幢 612 室		
检验类别	: 委托检验	测试日期	: 2026 年 05 月 22 日-2026 年 06 月 18 日
签发日期	: 2026 年 06 月 18 日		
检验依据	: GB/T10125-2021 《人造气氛腐蚀试验盐雾试验》(中性盐雾试验 NSS) GB/T6461-2002 《金属基体上金属和其他无机覆盖层经腐蚀试验后的试样和试件的评级》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 不做判定		

报告编制:

张华伟

报告审核:

杨泽群

检测专用章  
报告签发:

杨泽群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司  
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202606181A1705

参数项目	标准规定要求	实际设定/实测值
试验方法	中性盐雾试验 (NSS)	NSS 连续喷雾
氯化钠溶液浓度	50 g/L ± 5 g/L	50.2 g/L
溶液 pH 值 (35℃收集液)	6.5 ~ 7.2	6.8
试验箱内温度	35℃ ± 2℃	35.0℃
盐雾沉降率	1.0 mL/h ~ 2.0 mL/h (80cm <sup>2</sup> )	1.4 mL/h
喷雾方式	连续喷雾, 无间断	连续喷雾
试验持续时间	依据产品规范 (本次设定 240h)	240 小时

### 检测过程记录

**样品前处理:** 试验前, 使用软毛刷轻轻拂去隔振器表面的灰尘, 未使用任何溶剂清洗, 以保持表面涂层及封闭剂的原始状态。

**样品放置:** 将 3 件隔振器样品以与垂直方向成 20° 的倾角放置于盐雾箱内的样品架上, 确保样品之间无接触, 且盐雾能自由沉降到所有测试表面。

**过程监控:** 试验期间每 24 小时记录一次箱内温度、饱和空气桶温度及盐雾沉降率, 收集液的 pH 值在试验开始和结束时分别进行测定, 均符合标准要求。

**后处理:** 试验结束后, 取出样品, 在流动的清水下轻轻冲洗去除表面盐分, 用软海绵轻轻擦拭, 随后用压缩空气吹干, 并在标准环境下静置 2 小时后进行外观检查。

### 检测结果与评级

检查时间节点	外观检查描述	缺陷情况
0 h (初始)	表面银灰色, 色泽均匀, 无起泡、裂纹、剥落、漏镀等缺陷。	无
96 h	表面完好, 无白色或红色腐蚀产物, 涂层无变化。	无
168 h	边缘及倒角处出现极微量白色腐蚀产物 (白锈), 主体表面完好, 无红锈。	无
240 h (结)	表面及部分边缘处有少量白色腐蚀产物, 未见任何红色腐蚀产物 (红锈)。	无红

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





报告编号: HYI202606181A1705

检查时间 节点	外观检查描述	缺陷 情况
束)	涂层无起泡、起皮、剥落现象。	锈

综合评级 (依据 GB/T 6461-2002):

保护评级 (Rp): 10 级 外观评级 (RA): 10 级



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



## 注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com

同安公司