



检 测 报 告

Test Report

送检企业: 佛山市星光固创五金制品有限公司

样品名称: 电 机

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260703A1749

样品名称	:	电机	规格型号	:	63ZY24-15-02
商标	:	LINIX	样品数量	:	1 PCS
委托单位	:	佛山市星光固创五金制品有限公司			
委托单位地址	:	佛山市顺德区龙江镇世埠社区龙丰路 10 号之 2 号			
生产单位	:	浙江联宜电机有限公司			
生产单位地址	:	浙江省金华市东阳市横店镇工业大道 196 号			
检验类别	:	委托检验	测试日期	:	2026 年 07 月 02 日-2026 年 07 月 03 日
签发日期	:	2026 年 07 月 03 日			
检验依据	:	GB/T 755-2019 《旋转电机 定额和性能》 GB/T 12350-2022 《小功率电机的安全要求》			
检验项目	:	见后续			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	63.8%
测试结果	:	本次委托检验, 所检项目全部符合标准要求			

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



检测报告

序号	检测项目	检测指标	检测结果	单项判定
1	电源电压	220 V	220 V	合格
2	电机空载输入功率	28W(±5%)	26-29 W	合格
3	空载电流	0.15A (±0.2%)	0.14-0.155 A	合格
4	电机空载转速	1460(±5%) r/min>	1460 r/min	合格
5	减速机噪音	≤50 分贝	≤50 分贝	合格
6	调速范围	90-140 r/min	90-140r/min	合格
7	齿轮箱空载输出转速	8(±0.03%) r/min	8.3r/min	合格
8	电机转向	连接 CW 时顺时针	符合	合格
9		连接 CW 时逆时针	符合	合格
10	电阻	158 欧姆(± 2%)环境温度 15C	157-165 欧姆	合格
11	耐压检测	试验电压 1760V/漏电电流 10mA/历时 1S、无警报声、 执行标准 GB12350	无声警报	合格
12	电机外观	表面光洁、漆膜均匀、联接紧固、无松动现象、标志字 迹清晰、正确、完整、不易磨灭、不松动、有良好的电 连接、接地装置有接地标志	符合 GB/T 7345 相关要求	合格
备注: 电容 2vF/500V				

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报 告 编 号: HYI20260703A1749

样品照片



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址：福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province.

邮箱: hongyotest@123.com



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com