



# 检测报告

## Test Report

送检企业: 本溪市炬昌餐饮服务中心

样品名称: 生活饮用水

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司  
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260527A0933

|         |   |                                                        |      |   |                                   |
|---------|---|--------------------------------------------------------|------|---|-----------------------------------|
| 样品名称    | : | 生活饮用水                                                  | 型号规格 | : | /                                 |
| 商标      | : | /                                                      | 样品数量 | : | 10 L                              |
| 委托单位    | : | 本溪市炬昌餐饮服务中心                                            |      |   |                                   |
| 委托单位地址  | : | 辽宁省本溪市经济技术开发区神农大街 18-6 栋                               |      |   |                                   |
| 生产单位    | : | 本溪市炬昌餐饮服务中心                                            |      |   |                                   |
| 生产单位地址  | : | 辽宁省本溪市经济技术开发区神农大街 18-6 栋                               |      |   |                                   |
| 检验类别    | : | 委托检验                                                   | 测试日期 | : | 2026 年 07 月 05 日-2026 年 07 月 14 日 |
| 签发日期    | : | 2026 年 07 月 14 日                                       |      |   |                                   |
| 检验依据    | : | GB/T 5750-2023《生活饮用水标准检验方法》<br>GB 5749-2022《生活饮用水卫生标准》 |      |   |                                   |
| 检验项目    | : | 见后续                                                    |      |   |                                   |
| 样品特征和状态 | : | 完好                                                     |      |   |                                   |
| 环境温度    | : | 24.6℃                                                  | 环境湿度 | : | 63.8%                             |
| 测试结果    | : | 本次委托检验, 所检项目全部符合标准要求                                   |      |   |                                   |

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



## 检测报告

| 序号 | 检测项目   | 单位          | 检测指标    | 检测结果    | 判定 |
|----|--------|-------------|---------|---------|----|
| 1  | 总大肠菌群  | (MPN/100mL) | 不得检出    | 未检出     | 合格 |
| 2  | 大肠埃希氏菌 | (MPN/100mL) | 不得检出    | 未检出     | 合格 |
| 3  | 菌落总数   | (CFU/mL)    | ≤100    | 未检出     | 合格 |
| 4  | 砷      | (mg/L)      | ≤0.01   | <0.001  | 合格 |
| 5  | 镉      | (mg/L)      | ≤0.0005 | <0.0005 | 合格 |
| 6  | 铬(六价)  | (mg/L)      | ≤0.05   | <0.004  | 合格 |
| 7  | 铅      | (mg/L)      | ≤0.01   | <0.0025 | 合格 |
| 8  | 汞      | (mg/L)      | ≤0.001  | <0.0001 | 合格 |
| 9  | 氰化物    | (mg/L)      | ≤0.05   | <0.004  | 合格 |
| 10 | 氟化物    | (mg/L)      | ≤1      | <0.03   | 合格 |
| 11 | 硝酸盐    | (mg/L)      | ≤10     | 5       | 合格 |
| 12 | 三氯甲烷   | (mg/L)      | ≤0.06   | 0.0015  | 合格 |
| 13 | 一氯二溴甲烷 | (mg/L)      | ≤0.1    | <0.02   | 合格 |
| 14 | 二氯一溴甲烷 | (mg/L)      | ≤0.06   | 0.0013  | 合格 |
| 15 | 三溴甲烷   | (mg/L)      | ≤0.1    | <0.02   | 合格 |
| 16 | 三卤甲烷   | (mg/L)      | ≤1      | <0.03   | 合格 |
| 17 | 二氯乙酸   | (mg/L)      | ≤0.05   | 0.0011  | 合格 |
| 18 | 三氯乙酸   | (mg/L)      | ≤0.1    | <0.02   | 合格 |
| 19 | 溴酸盐    | (mg/L)      | ≤0.01   | <0.0025 | 合格 |
| 20 | 亚氯酸盐   | (mg/L)      | ≤0.7    | 0.4     | 合格 |

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



|    |                |          |             |        |    |
|----|----------------|----------|-------------|--------|----|
| 21 | 氯酸盐            | (mg/L)   | $\leq 0.7$  | 0.5    | 合格 |
| 22 | 色度             | (铂钴色度单位) | $\leq 15$   | <5     | 合格 |
| 23 | 浑浊度            | (NTU)    | $\leq 1$    | <0.5   | 合格 |
| 24 | 臭和味            | /        | 无异臭异味       | 无异臭异味  | 合格 |
| 25 | 肉眼可见物          | /        | 无           | 无      | 合格 |
| 26 | pH             | (无量纲)    | 6.5~8.5     | 8.18   | 合格 |
| 27 | 铝              | (mg/L)   | $\leq 0.2$  | 0.085  | 合格 |
| 28 | 铁              | (mg/L)   | $\leq 0.3$  | <0.05  | 合格 |
| 29 | 锰              | (mg/L)   | $\leq 0.1$  | <0.02  | 合格 |
| 30 | 铜              | (mg/L)   | $\leq 1$    | <0.03  | 合格 |
| 31 | 锌              | (mg/L)   | $\leq 1$    | <0.03  | 合格 |
| 32 | 氯化物            | (mg/L)   | $\leq 250$  | 150    | 合格 |
| 33 | 硫酸盐            | (mg/L)   | $\leq 250$  | 27.92  | 合格 |
| 34 | 溶解性总固体         | (mg/L)   | $\leq 1000$ | 208    | 合格 |
| 35 | 总硬度            | (mg/L)   | $\leq 450$  | 137.6  | 合格 |
| 36 | 高锰酸盐指数         | (mg/L)   | $\leq 3$    | 1.75   | 合格 |
| 37 | 氨              | (mg/L)   | $\leq 0.5$  | 0.35   | 合格 |
| 38 | 总 $\alpha$ 放射性 | (Bq/L)   | $\leq 0.5$  | <0.028 | 合格 |
| 39 | 总 B 放射性        | (Bq/L)   | $\leq 1$    | <0.07  | 合格 |
| 40 | 游离余氯           | (mg/L)   | 0.3~4       | 0.80   | 合格 |
| 41 | 总氯             | (mg/L)   | $\leq 3$    | 1      | 合格 |
| 42 | 臭氧             | (mg/L)   | $\leq 0.3$  | 0.15   | 合格 |
| 43 | 二氧化氯           | (mg/L)   | $\leq 0.8$  | 0.4    | 合格 |

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



## 注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

\*\*\*报告结束\*\*\*

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司  
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com