



检测报告

Test Report

委托单位: 阳江市家点赞家居用品有限公司

样品名称: 剪刀

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260730A1535

样品名称	:	剪刀	型号规格	:	/
商标	:	/	样品数量	:	6 把
委托单位	:	阳江市家点赞家居用品有限公司			
委托单位地址	:	阳江市阳东区东城镇永兴五路 40 号			
生产单位	:	阳江市家点赞家居用品有限公司			
生产单位地址	:	阳江市阳东区东城镇永兴五路 40 号			
检验类别	:	委托检验	测试日期	:	2026 年 07 月 24 日-2026 年 07 月 30 日
签发日期	:	2026 年 07 月 30 日			
检验依据	:	GB 4806.9-2023 《食品安全国家标准 食品接触用金属材料及制品》			
检验项目	:	见后续			
样品特征和状态	:	完好			
环境温度	:	24.6℃	环境湿度	:	63.8%
测试结果	:	本次委托检验, 所检项目全部符合标准要求			

报告编制:

张华伟

报告审核:

杨泽群

报告签发:

杨泽群

检测专用章

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260730A1535

检测结果:

序号	检验项目	单位 符号	标 准 要 求	检验 结果	单项评价
1	刃口硬度(HRC)	无	≥ 52	52 52 53 53 52 52	合 格
			两片刃口对应点硬度差: ≤ 4	1 0 1	合 格
2	剪切性能	无	优等品、一等品应手易轻松、均匀,剪布锋利,不咬口、崩口、变形。合格品手感可欠轻松、均匀。	手感轻松。 均匀	合 格
3	粗 糙 度 (R a)	μm	里口面: ≤ 6.3	0.6	合 格
			外口面 ≤ 6.3	1.6	合 格
4	剪 体	无	剪体平整。	符 合	合 格
5	商 标	无	商标字迹清晰、端正	符 合	合 格
以下空白					

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com