



检测报告

Test Report

送检企业: 安徽赛丽金属科技股份有限公司

样品名称: 废气、噪声

检验类别: 委托检验



厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260708A1741

1. 检测信息

客户基本情况

客户基本情况				
委托单位信息	单位名称	安徽赛丽金属科技股份有限公司		
	通讯地址	芜湖三山经济开发区临江工业园纬二路		
	联系人	王娟	联系电话	15979438787
受检单位信息	单位名称	安徽赛丽金属科技股份有限公司		
	通讯地址	芜湖三山经济开发区临江工业园纬二路		
	联系人	王娟	联系电话	15979438787

样品基本情况

样品类别	样品名称	采样点位	采样频次		采样人员	采样时间	收样人员	收样时间	分析时间	样品状态描述
			天数	次/天						
废气	废气(有组织)	DA001， DA002	1	3	郭浩	2026.07.05	王明轩	2026.07.06	2026.07.05-2026.07.08	完好
噪声	昼夜噪声	厂界四周	1	3	郭浩	2026.07.05	王明轩	2026.07.06	2026.07.05-2026.07.08	完好

报告编制: 张华伟

报告审核: 杨群

报告签发: 杨群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报 告 编 号: HYI20260708A1741

1. 检测分析方法

1.1 有组织废气

表格

检测项目	分析方法	标准依据	检出限
低浓度颗粒物	重量法	HJ 836-2017	1.0mg/m ³

1.2 噪声

表格

检测项目	分析方法	标准依据
厂界噪声	声级计测量法	GB 12348-2008

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报 告 编 号: HYI20260708A1741

2. 检测结果

2.1 有组织废气排放口处检测结果

采样口	检测项目		检测结果			许可排放限值	结果评价
			第一次	第二次	第三次		
DA001	标干流量 (m ³ /h)		2578	2625	2535	—	—
	低浓度颗粒物	浓度 (mg/m ³)	8.5	10.0	7.4	30	达标
		排放速率 (kg/h)	0.011	0.010	0.013	—	—
采样口	检测项目		检测结果			许可排放限值	结果评价
			第一次	第二次	第三次		
DA002	标干流量 (m ³ /h)		2578	2625	2535	—	—
	低浓度颗粒物	浓度 (mg/m ³)	8.5	10.0	7.4	30	达标
		排放速率 (kg/h)	0.011	0.010	0.013	—	—

2.2 废水检测结果

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20260708A1741

2.3 噪声检测结果

采样时间	检测点位	检测时间	检测结果 dB(A)	限值	结果评价
			Leq		
2026.07.06	东界	昼间	56.1	60-50	达标
		夜间	48.1		
	南界	昼间	57.6		达标
		夜间	45.0		
	西界	昼间	57.8		达标
		夜间	47.5		
	北界	昼间	56.5		达标
		夜间	48.0		

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20260708A1741

附: 噪声检测布点



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



检测报告



中国认可
国际互认
检测
TESTING
CNAS L9023

第 7 页 共 7 页

报告编号: HYI20260708A1741

注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意, 不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议, 应于收到报告之日起十五日内向检测单位提出, 逾期不予受理。
6. 委托检测仅对来样负责。

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com